



Tru Hone Cover Removal Instructions

1. Loosen screws holding black honing wheel cover & remove cover.

 2. Remove honing wheels & both sets of brass washers.

 3. Remove eight screws on lower portion of both sides & front of Tru Hone.

 4. Turn Angle Adjustment Knob counterclockwise until it disengages from threaded camrod.
*Black bushing may come out.

 5. Raise back of stainless steel cover over motor & slide cover forward off honing wheel shafts.
- *** If black bushing comes out, replace it with bushing provided after Tru Hone has been reassembled & Angle Adjustment Knob has been turned down to sharpening position. Remove Angle Adjustment Knob by loosening set screw & insert new bushing.