

Preventive Maintenance Schedule and Recommended Stock Items

Daily	HG3	HR8	HCA	Preventive Maintenance
	√	√	√	Clean machines
	✓	√		Inspect coolant level
			√	Add water to sponge (TH1242 Honing Wheel Cover only)
Weekly				
	✓	√		Rotate diamond dresser bits ¼ turn
	✓	√		Clean sock filter & tray filter
			✓	Clean or replace wet tray sponge
	✓	✓		Change coolant (3 cups additive per coolant tank of water)
	√	√		Drain air/water separator
	✓	√	✓	Inspect grinding & honing wheels
Monthly				
	✓	✓		Replace sock filter
	✓	✓		Inspect diamond dresser bits
	✓	✓		Inspect hydraulic oil levels
Quarterly				
	✓	✓		Replace tray filter
	✓	✓		Apply anti-seize to dresser ram assemblies & dresser slide rods
Annually				
	√	✓		Inspect motor bearings
	✓	✓		Remove main covers & clean as necessary
Quantity	Item #		ŧ	Recommended Stock Item Description
1 set	HG37122			Hollow Grinder Wheels Complete Set (Standard 54 grit)
1 set	HR87125			Honing Wheels Complete Set (Standard 220 grit)
1 set	HW1000/1500		500	Honing/Polishing Wheels Complete Set (1000 or 1500 grit)
4 ea.	TH1716			Sponge (TH1242 Honing Wheel Cover only)
1 ea.	CLD6			Cleaner 6 oz. (TH1242 Honing Wheel Cover only)
4 ea.	CLST			Cleaning/Dressing Stick
2 ea.	HGH7201			Filter, Sock
2 ea.	HGH7211			Filter, Tray
1 ea.	HGH7112			Additive, Grinding Coolant - 5 gallons - USDA Approved
2 ea.	HGH1304			Dresser Bit, Diamond 6" (¼ Carat)
3 ea.	HGH4212			Bearing, Motor (Small) (Front & Rear HR8) (Rear HG3)
1 ea.	HG34213			Bearing, Motor (Large) (Front HG3)
1 ea.	HG34201			Motor (HG3 Hollow Grinder)
1 ea.	HR84201			Motor (HR8 Honer)

TRU HONE CORPORATION